

# NOCHAR'S A680 FACT SHEET

## APPLICATION:

Dry granular material used to immobilize bodily fluids, blood, urine and vomit spills. A680 will bond the liquid and reduce the possibility of being contaminated by splashing, spilling or splatters.

## RECOMMENDED APPLICATION RATE:

The amount of product to be used will depend on the type of spill and which of the fluids is being solidified. Spread A680 evenly on the surface of a spill, and allow solidification process to occur. Some examples of the bonding ratios are:

<u>FLUID</u>	<u>RATIO</u>
Blood	18:1
Urine	21:1
Vomit	15:1

## SPECIFIC GRAVITY:

.82

## WEIGHT BY VOLUME:

One pound equals 34 cubic inches.

## FLASH POINT:

N/A

## PH SPECIFICATIONS:

Neutral

## TOXICITY:

This product is non-toxic, non-hazardous; see Material Safety Data Sheet.

## TYPES OF MATERIAL TO BE TREATED:

Human blood, human blood components, products made from blood, urine, vomit, bodily fluids such as semen, vaginal secretions, cerebrospinal fluid, synovial fluid, pleural fluid, pericardial fluid, peritoneal fluid, amniotic fluid, saliva in dental procedures, any bodily fluid that is visibly contaminated with blood, and all bodily fluids in situations where it is difficult or impossible to differentiate between bodily fluids.

**STORAGE SPECIFICATIONS:**

Keep container sealed unless using; keep free of contamination.

**METHOD OF DISPOSAL:**

Extreme caution must be exercised when handling, storing and disposing of solidified or gelled hazardous materials. COMPLIANCE: Solidified or gelled materials must be disposed of in accordance with federal, state and local laws and regulations. The user is solely responsible for compliance with disposal laws and regulations. The manufacturer or seller assumes no responsibility for the proper disposal of solidified or gelled materials.